

Attraction™

Tension Fabric Banner Stand

SETUP INSTRUCTIONS



1. Remove aluminum tubes from case and assemble. NOTE: All tubing is corded together.



2. If you have shelves, make sure to attach the support socket to the uni-pole.




3. Slide uni-pole onto base unit.



4. Lift the fabric print to the top. Tilting the stand toward you will make this job much easier.




5. Stretch fabric graphic over top pole. Avoid putting unnecessary stress on zipper.



6. Zip up top of the print half way on both sides.

Note for Attraction™ Straight Top: Make the profile shorter before stretching the fabric, then extend the center pole to its full height position.



7. Place the base of the light fitting in the hole in the middle of the profile.



8. Attach lights and run electrical cords inside the print. You may now finish closing the zipper.



9. Slide shelf through the open slit in the print and fit it onto the support socket.



10. Use same method to attach the catalog holder.