


Streamline™

MODULAR EXHIBIT SYSTEM

STREAMLINE™ TENSION FABRIC COUNTER SETUP INSTRUCTIONS



1. Remove the counter from the carry bag.



2. Extend and lock the support poles.




3. Place the three poles into the base with the holes facing up.



4. Place counter top onto poles. Tap down with hand to secure.



5. Slide fabric graphic wrap onto hardware. Align seam to center of back of counter.



6. Angle and tuck gasket into channel in edge of counter top. Insert graphic gasket all the way around.



7. Flip counter upside-down.



8. Pull graphic taught and angle and tuck gasket into channel in edge of base. Insert graphic gasket all the way around.



9. Flip counter back to upright position.



10. The zipper on the back is used to access the inside of the unit.